



Quick Connect Drain Kit -- Installation Instructions

1. Drill a 4" hole in your wooden subfloor.
-



2. Measure the distance from the inside of the P-trap to the top of the floor.
(P-Trap not included)
-



3. Cut the ABS or PVC 1 1/2" pipe 3" shorter than the distance between the floor and the P-trap.
-




4. Apply glue to the outside of the ABS or PVC 1 1/2" pipe and to the inside of the P-trap.
-

Insert the pipe into the P-trap.




5. Apply glue to the outside of the ABS or PVC 1 1/2" pipe and to the inside of the Drop-In drain insert.
-




6. Slide the Drop-In Drain on the ABS or PVC 1 1/2" pipe making sure it sits flat on the floor.


*Please refer to local acceptable plumbing code in regards to use of protective membrane/underlayment.



7. Insert the Drop-In Drain cap firmly into the Drop-In Drain.
-



8. Secure the Drop-In Drain to the subfloor with screws or cement.
-




9. Install your flooring surface around the opening of the Drop-In Drain.
-



10. Remove the Drop-In Drain cap with a channel lock plier.
-



11. Apply provided lubricant inside the Drop-In Drain
- Please only proceed with this step once the pressure test has been performed, if needed.
-



12. Affix the appropriate tailpiece to the waste & overflow.

Ensure the measurement between the base of the Drop-In Drain and the P-trap will accommodate the tailpiece.

Warning : Do not cut the brass tailpiece as this may cause leakage.



13. Apply provided lubricant halfway up the tailpiece and position the bathtub and tailpiece in line with the Drop-In Drain.
-



14. With caution, slowly insert the bathtub tailpiece into the Drop-In Drain.
-



Please refer to local acceptable plumbing codes for installation.
May not be compatible with certain MTI tub models.
Contact MTI Baths' Service Department with any questions.